



## High Performance Bio-based Functional Coatings for Wood and Decorative Applications

### PERFE COAT

High Performance Bio-based  
Functional Coatings for Wood and  
Decorative Applications

**Bio-based innovations for  
industrial applications**

**BIP Meeting Centre, Brussels**

**Simone Schulte – Evonik Coating Additives**

**[simone.schulte@evonik.com](mailto:simone.schulte@evonik.com)**



This project receives funding from the Bio-based Industries Joint Undertaking (JU) under the European Union's Horizon 2020 research and innovation programme under grant agreement No 101022370. The JU receives support from the European Union's Horizon 2020 research and innovation programme and the Bio-based Industries Consortium.



## High Performance Bio-based Functional Coatings for Wood and Decorative Applications



# Bio-based coating formulation and application testing

Bio-based Innovations for Industrial Applications  
24 April 2024



This project receives funding from the Bio-based Industries Joint Undertaking (JU) under the European Union's Horizon 2020 research and innovation programme under grant agreement No 101022370. The JU receives support from the European Union's Horizon 2020 research and innovation programme and the Bio-based Industries Consortium.

## Paint & Coating Fundamentals

Coatings are everywhere!



plastic



glass



mineral  
substrate



paper



wood



metal



leather

## Overview on typical coating components



**Binders:** provide film forming, major impact on durability and mechanical resistance of coatings and mechanical properties.



**Fillers:** powder material used to fill and give body to the coating, influence mechanical film properties, hiding power, etc.




**Pigments:** solid, powder particles that provide color to the coating



**Additives/functional ingredients:** materials used in very small amount to control specific properties and increase the quality of the coatings



**Solvents/water:** enable a smooth production of the coating and ensure good processability. The PERFECOAT project focuses on the development of water-based or solvent-free coatings



# Testing of basic properties

**Bio-based fillers: Assessment of the basic properties within an architectural coating formulation**

**Key properties: Decorative aspect / White color / Mechanical resistance**


## Test formulation

Matt wall paint	Amount in g
Water	42,76
TEGO® Dispers 711W	0,25
TEGO® Foamex 18	0,25
CALGON® N	0,05
NATROSOL™ 250BR	0,60
KRONOS® 2190	6,70
SOCAL® P3	12,56
LUZENAC® OOC	5,02
OMYACARB® 5 GU	23,44
ACRONAL® S790	8,37
TOTAL	100,00


High filler content of 41%

## Test equipment

Wet scrub tester



## Test result



Color change and lower abrasion resistance of the prototype bio-based filler (left side) compared to the standard (right side)

# Testing of basic properties

## Micro fibrillated cellulose (MFC) for Architectural Coatings



### Evaluation of the effect of bio-based fibers (EXILVA®) on rheology and cracking resistance in architectural coatings

#### Test formulation

Component	Standard	Exilva
Water	27.6	24,4
CALGON® N	0.1	0.1
Defoamer	0.3	0.3
TEGO® Dispers 715 W	0.3	0.3
TYLOSE® MH 30.000 YP 4	0.4	0
Ammonium hydroxide sol.(25 %)	0.1	0
Exilva F01 V, 10% a.m.		3.6
TIOXIDE® R-TC 90	9.0	9.0
OMYACARB® 10 GU	8.0	8.0
OMYACARB® 2 GU	8.0	8.0
OMYACARB® Extra CL	5.0	5.0
LUZENAC® OOC	2.0	2.0
SOCAL® P3	5.0	5.0
Dissolver 30 min.		
ACRONAL® S 790	32.0	32.0
Texanol	2.0	2.0
ACTICIDE® MBS	0.2	0.2
Acrysol RM2020		1.7
Total	100.00	100.00

#### Test equipment & result rheology

Use of bio-based MFC allows to adjust the rheological profile in the desired way



#### Test result

Favourable cracking resistance of thick films



# Testing of basic properties

**Bio-based pigments in water-based architectural coatings – architectural paints are often white but end consumers also want to be able to obtain various colors**

## Test formulation for a water-based pigment preparation

Component	Amount [g]
Demin. Water	44.4
ZETASPERSE® 3800	22.5
TEGO® Foamex 810	1.0
AMP-90	2.0
Pigment	30.0
Parmetol K6	0.1
Total	100.0
AsoP [%]	30

## Test equipment

Ultrasonic dispersion method established for small quantity bio-based pigment samples



## Test result

Bio-based pigments provide quite intensive colors



Challenge:  
Stability of color after long-term storage


# Testing of basic properties

## Bio-based filler / functional additive for UV-curable wood coatings


### Test formulation

Component	Amount (g)
Ebecryl 5129 (resin)	30
TPGDA (reactive diluent)	33
TMPEOTA (ethoxylated trimethylolpropane, triacrylate - resin)	30
TEGO Rad 2100 ( surface control)	0.6
Genocure MBF (initiator)	2.2
Darocure 1173 (Initiator)	2.2
i-Propanol (Diluent)	2.0

### Test equipment: Mini Martindale abrasion tester



### Test result





The addition of POSS to the UV wood coating enhances the mechanical resistance

- Less scratches are seen at the surface compared to a reference without POSS



# Polyoctahedral silsesquioxanes (POSS) as Filler for UV coatings

## Quantitative assessment of scratch resistance



FN03012


- Quantitative assessment of percentage of scratched surface using Evonik proprietary Defect Detection Tool software
- Effect of FN03012 comparable to benchmark
- Optimum concentration around 7.5%
- No synergy between benchmark and POSS

# Biomass as Fillers for UV curable wood coating

## Assessment of basic properties in model UV-curable coating: Scratch resistance and Matting effect

Analyze surface topography with Keyence VK-X 3100 profilometer

Martindale test





**Yeast samples (Technische Universität München):**  
Was treated/bleach and unbleached yeast

**Test:**

- Analyze surface topography with Keyence VK-X 3100 profilometer
- Scratch resistance tested with mini-Martindale tester
- Gloss measurement
- Resistance to water and Ethanol test

**Results:**

Although the use of wax treated yeast in UV-curable coatings does not give the desired level of matting and scrub resistance, combination with ACEMATT® 3600 can give acceptable gloss and scrub resistance with higher level of bio-based content in formulation.



	gloss		Martindale / rough pad	Chemical resistance H <sub>2</sub> O (PMMA panels)		Chemical resistance H <sub>2</sub> O + Ethanol 1:1 (wood panels)	
15% ACEMATT® 3600	60°	85°	50 rubs	2 h	4 h	2 h	4 h
15% ACEMATT® 3600	23.4	80.7	light damage	ok	ok	ok	ok
30% yeast 3	42.5	82.5	damaged	ok	ok	very soft	very soft
15% yeast 3 + 15% ACEMATT® 3600	27.1	81.9	light damaged	ok	ok	soft	soft

## Testing of basic properties

**Binders for water-based respectively UV-curable formulations**


**Oligosaccharides & their film forming properties – modification needed to meet requirements of coating application**

**Draw-down of aqueous alginate solution shows good film formation**



**Water resistance test (a water droplet is placed onto dried film and removed after short waiting time)**

Alginate (2% solution)



Xanthan Gum (2% solution)



Challenge: water resistance of non-modified oligosaccharides  
The film is degraded due to water redissolution

## Summary

- Samples of multiple bio-based components for coating formulations were assessed regarding key properties
- Bio-based pigments could be processed & provide good color development but long-term stability of color not sufficient yet
- Incorporation of bio-based fillers could be easily achieved but mechanical resistance needs improvement
- Bio-based micro fibrillated cellulose shows expected rheology modification as well as benefits in mud cracking performance
- Addition of modified POSS leads to benefits in resistance
- Binder development is a more complex task

**Thank you for your attention !**